

# PARKAID

## Backup Distance Sensing System

Designed to work on trucks, buses, etc. to provide a distance measurement in feet or meters from the rear of the vehicle to the obstacles behind the vehicle. Obstacles such as loading docks, other vehicles, fences, posts, etc. The TEACO PARKAID utilizes ultrasonic sensors to detect objects in its radiated beam sensing area. There are four different versions to fit all of your needs. You can also get additional sensors, external alarm and external speaker. The speaker tells you how close you are in feet or meters, so you can keep your eyes on your mirrors. The PARKAID is a must have for reversing safely.

Digital display on dash.

Sensor (up-close)



PARKAID 16C installed with an extra sensor (optional).



**M. S. Foster & Associates, Inc.**

1866 N. Country Lane, Michigan City, IN 46360  
Phone 219-380-3266 or 219-879-9225 • Toll Free 888-452-4053  
Fax 219-879-9313 • email: [sales@msfoster.com](mailto:sales@msfoster.com)  
[www.msfoster.com](http://www.msfoster.com)



## PARKAID 16A

Display/controller on dash. With (1) Sensor (1) 25 ft. Sensor cable, 6 ft. power cable and sensor mounting hardware. External alarm (optional).



## PARKAID 16B

Display/controller on dash. With (1) Sensor (1) 25 ft. Sensor cable, 6 ft. power cable and sensor mounting hardware.



## PARKAID 16C

Control module mounts under dash, with a 2 digit .56" high display suitable for mounting on an external mirror, on the dash or column. 6 ft. power cable, (1) Sensor (1) 25 ft. Sensor cable, mounting bracket and sensor mounting hardware. External alarm (optional).



## PARKAID 16D

Control module mounts under dash, with a 2 digit .56" high display suitable for mounting on an external mirror, on the dash or column. 6 ft. power cable, (1) Sensor (1) 25 ft. Sensor cable, mounting bracket and sensor mounting hardware.



### Optional Accessories



Additional Sensors



External Alarm 16A & 16C



3 Watt External Speaker for 16C



5 Watt External Speaker for 16C