

OPERATING INSTRUCTIONS

A Check that your onspots are working properly before your trip.

A Chains **MUST BE** engaged and disengaged while the vehicle is moving.

- chains MUST BE engaged when traveling between 2 mph and 25 mph.
- chains MUST BE disengaged when traveling between 2 mph and 35 mph.
- A Vehicle MUST NOT exceed 35 mph with the chains engaged.
- A Vehicle can stop on the chains, and then start moving again, as long as the switch is still in the engaged position.
- ▲ Engage chains before reaching slippery conditions. Onspot will assist traction in forward, reverse, and in braking conditions.
 - avoid locking the wheels.
- If you have not engaged your onspots before stopping on a slippery road:
 - spin tires up to 5 mph,
 - engage onspots,
 - when you feel chains bite, stop spinning wheels and drive on slowly

